



Vol. 2 No. 4

**'Short' Notice: How Internal Rebound Springs** Affect a Strut's Measured Length

SERVICEGRAM

Service providers replacing struts on certain vehicle models might notice that the recommended replacement Monroe<sup>®</sup> struts for those vehicles have a slightly shorter length, compared to the struts being replaced. This difference might require a minor change in the way service providers install the coil spring, upper mount and other components.

**Exclusive Ride Control Technology Solution** 

These differences do <u>not</u> reflect a design or manufacturing error. Rather, they indicate that the corresponding struts are equipped with OE *internal rebound spring technology*.

## What is an Internal Rebound Spring?

Internal rebound springs are used in several Monroe struts designed for vehicles that were originally equipped with this technology. The internal spring helps keep the strut rod and piston near factory static ride height during normal operation and enables the vehicle manufacturer to use lighter-weight and/or smaller-diameter anti-sway bars. Replacement struts equipped with this technology will appear slightly shorter than conventional struts when fully extended.

## Don't Use a Conventional Strut

The internal rebound spring provides additional resistance to vehicle lean and sway, a key characteristic for vehicles equipped with lighter-weight and/ or smaller-diameter anti-sway bars. Therefore, if the vehicle was originally equipped with internal rebound spring technology, it is important to install a replacement strut featuring the same design to avoid potential ride and handling complaints from the customer.

## **Installation Tips**

A strut equipped with an internal rebound spring uses the force of suspension motion to fully extend. As a result, special servicing procedures are required. To assemble the coil spring, upper mount and other module components onto the strut, it is important to position the spring compressor to contain as many coils as possible. The best

approach is to place the upper "fingers" of the spring compressor onto the upper spring seat and the lower "fingers" on the lowest open coil.





## Join Us On Tech Talk!

Share your questions, suggestions and other information with our ASE certified technical representatives and your peers across North America.



www.monroe.com/support/tech-talk

USA: 1 (734) 384-7809 Canada: 1 (734) 384-7811 (8:30 am – 5:30 pm EST, Monday-Friday)